

Date: May 2015 Effective Date: Immediately

## INTERPRETATION

2015-2

**What:** Definition of a Sleeping Area. NFPA 72, Section 18.4.5, 2010 edition

Sleeping areas shall be defined as the bedrooms listed on the approved building permit.

Why: The purpose of defining sleeping areas is to provide clarity to fire alarm installers when low

frequency sounders are to be installed. Low frequency sounders are required in all sleeping

areas.